



Residential 7x7 Zone Screen

IMPORTANT: Please read directions thoroughly before assembling your Zone Screen.

1. Take all parts out of the box.
2. Lay out the frame and proceed to connect all of the pieces, as shown in the diagram.
3. For an extra secure frame, use the included drill bit to put self-tapping screws at each joint. Make sure that the head is facing the **inside** of the frame to prevent net and ball wear.
4. Lay out the net and slide it over the frame like a pillow case over a pillow. Pull the bottom rope tight and tie.

