

Catch Net Assembly Instructions



1. Make sure all parts are included.
2. Assemble the base of the frame first, then the upper parts. Make sure that the steel prongs on pipes #1 are facing the back of the net.
3. Find the steel corners of upper part of the net and attach them, one at a time, to the steel prongs on the two pipes #1.
4. Find the two steel corners on the lower part of the net and attach the S-Hook first and, then to the two optional holes on pipes #5.

<u>Part #</u>	<u>Qty</u>
Part 1	- 2
Part 2	- 2
Part 2-2	- 1
Part 3	- 2
Part 4	- 1
Part 5	- 2

