



### Instructions for the 40'x12'x10' Cimarron Frame Corners

The following parts are included for your frame. Please review the parts that you received with your batting cage and frame to be sure that you have all the parts listed.

**\*\*\*YOU WILL NEED TO PURCHASE 23 – 10' LENGTHS OF 1 1/4" THIN WALLED EMT AT LOWES, HOME DEPOT, OR SOME OTHER HARDWARE STORE.  
Lowe's Sku # - 72717 - Home Depot Sku # - 580023**

PART	QTY	
(A) 3-WAY CORNERS	4	YOU WILL NEED AN AREA ABOUT 43' LONG AND 17' WIDE.
(B) 4-WAY CORNERS	6	
(C) 16" PIPE W/REDUCED END	5	IT IS RECOMMENDED THAT YOU MARK OFF THIS AREA BEFORE STARTING.
(H) NET HANGERS	25	
(I) PIPE END CAPS	10	
(J) SELF-DRILLING SCREWS	5	NUT SETTER INCLUDED
(CL) 10' LENGTHS OF EMT***	23	NOT INCLUDED

#### CONSTRUCTING YOUR FRAME


1. Lay out two of the 3-way corners (A) 12' apart at one end, where your frame will be, with the 4" corner piece facing toward the other end of the frame.
2. Measure 40' from the first 3-way corners to the other end of the frame and lay out the other two 3-way corners (A) with the 4" corner piece facing the other end of the frame.
3. Lay out the 4-way arch corners (B) , between the end corners (A) so they are about 10' apart.
4. Assemble the five arch tops by attaching one 10' length of EMT (CL) to a 16" pipe (C).
5. The arch legs and the arch tops are each one 10' length of EMT (CL).
6. Complete assembling the arches by attaching the legs to each of the arch top corners (A) & (B).
7. Attach end caps (I) to the bottom of the legs (CL).
8. Stand up one end arch and the second arch. Attach two 10' runners (CL) between the arches. Stand up the third arch and attach two 10' runners (CL) between second arch. Continue to add the rest of the runners to complete your frame.
9. Insert a self drilling screw (J) at the joints between the 10' lengths of EMT (CL) and tighten down all corner bolts.
10. Your frame should end up being a little over 40'.

#### HANGING YOUR BATTING CAGE NET

1. Lay out your batting cage inside the frame and find the top three ropes and tie them to the end arch and then do the same to the other end.
2. Attach the hanger clips to the rope and the net together along one side of the net, then the middle, and then the other side. If you do not get the rope and the net together, it will not hold up your net. Then take the lanyard part of the hanger and tie it around the cable. At this point you can adjust how tight you want the net to hang.
3. Tie the bottom rope tails to the bottom part of the end arch legs to prevent the wind from blowing the net inward.

**To secure the frame, we recommend that you attach two 18' ropes to each end of the frame and stake the ropes to the ground. Ropes and stakes are not included.**

# 40x12x10



PART	QTY
(A) 3-WAY CORNERS	4
(B) 4-WAY CORNERS	6
(C) 16" PIPE EXTENSIONS	5
(H) NET HANGERS	25
(I) PIPE END CAPS	10
(J) SELF DRILLING SCREWS	5
(CL) 10' LENGTHS OF EMT	23

